



# Workabout Pro 4

Accessories Guide



# Step 1:

Choose the main Workabout Pro 4 variant



## Workabout Pro 4

- 7528-L** Workabout Pro 4 Long
- Windows CE 6.0
  - Windows Embedded Hand Held 6.5
- 7528-S** Workabout Pro 4 Short- Numeric  
Workabout Pro 4 Short- Qwerty
- Windows CE 6.0
  - Windows Embedded Hand Held 6.5

# Step 2:

## Choose a radio option



### Radio options



### Radios

- RA3051** HSPA+ WAN expansion module, compatible with Short and Long configurations, end-cap of choice is ordered separately.
- RA3052** Diversity Wi-Fi / Stand alone GPS antenna module, compatible with Short and Long configurations, end-cap of choice is ordered separately.

# Step 3:

## Choose a data capture method



### Data capture options

#### Slim Pod Engines

**WA9015** SE965 1D Standard range laser

**WA9017** SE655 1D Linear imager

**WA9019** SE4500 2D Imager

#### Optional pistol grip

**WA6003** Pistol grip attachment for slim pod



**WA6003**  
Pistol Grip



**WA9015**  
1D Standard range laser



**WA9017**  
1D Linear Imager



**WA9019**  
2D Imager



All slim pods and pistol grip are compatible with short and long configurations

# Step 3:

## Choose a data capture method



### Data capture options

#### End-Cap Engines

**WA9022** SE1524ER 1D Lorax extended range laser

**WA9016** SE965 1D Standard range laser

**WA9018** SE655 1D Linear imager

**WA9020** SE4500 2D Imager

#### Optional pistol grip

**WA6103** Pistol grip attachment kit. Includes flush mount pistol grip with trigger, and screws



**WA6103**  
Pistol Grip



When using WA9022 Lorax Laser end-cap with or without pistol grip, a trigger board WA9301 is required

For all other end-cap engines, a trigger board WA9302 is required **ONLY** when using the pistol grip.



**WA9022**  
1D Lorax Laser



**WA9016**  
1D Standard Range Laser



**WA9018**  
1D Linear Imager



**WA9020**  
2D Imager



All end-cap scanners and pistol grip are compatible with short and long configurations

# Step 3:

## Choose a data capture method



### Data capture options

#### Trigger Boards

**WA9301** Trigger board for SE1524-ER, 1D Lorax extended range laser end-cap.

**WA9302** Trigger board for 1D standard range laser or 1D/2D imager end-cap

#### Additional pistol grip

**WA6103** Pistol grip attachment kit. Includes flush mount pistol grip with trigger, and screws



**WA6103**  
Pistol Grip

! Trigger board WA9301 is always required when using WA9022 Lorax laser end-cap with or without pistol grip



**WA9301**  
Trigger Board for Lorax Laser End-Cap



**WA9302**  
Trigger Board for 1D Laser or 1D/2D Imager End-Cap

! Trigger board WA9302 is required for 1D laser or 1D/2D imager **ONLY** when using the pistol grip

! All trigger boards are compatible with short and long configurations



# Step 3:

## Choose a data capture method

### Other options

#### Back Cover and End-Cap Options

- |               |                                     |
|---------------|-------------------------------------|
| <b>WA6208</b> | Standard blank back-cover           |
| <b>WA6214</b> | Standard blank end-cap, with stylus |
| <b>WA6212</b> | WAN/GPS/Wi-Fi diversity end-cap     |
| <b>WA6213</b> | Multi-purpose end cap               |
| <b>WA9021</b> | 8.0 megapixel camera module         |
| <b>WA6215</b> | Headset adapter end-cap             |

All covers and end-caps are compatible with short and long configurations



**WA9021**  
8MP Camera Module



**WA6216**  
Standard Blank Back-Cover

# Step 3:

## Choose a data capture method

### **RFID options**

#### Ultra High Frequency (UHF)

- WA9901** Linear antenna, FCC and IC certified
- WA9902** Linear antenna, CE certified
- WA9903** Circular antenna, FCC and IC certified\*
- WA9904** Circular antenna, IC certified\*

All circular UHF antenna modules are installed to the WAP4 units as back-covers



#### High (HF) and Low Frequency (LF)

- WA9905** HF module, FCC, IC and CE certified
- WA9906** LF module



All RFID options are compatible with or without a WAN radio. Before choosing any combination, review the local country approval list.






# Step 4:

## Choose a battery type



### Spare Battery options

If you're changing battery types, a battery door is required when purchasing 3300 mAh or 4400 mAh batteries 

#### 2760 mAh Battery



**WA3025**  
Spare battery, 2760 mAh

#### Compatible battery doors:



**WA3015-G2**  
Battery door for **long** configurations



**WA3016-G2**  
Battery door for **short** configurations

#### 4400 mAh Battery



**WA3010**  
Spare battery, 4400 mAh

#### Compatible battery doors:



**WA3017-G2**  
Battery door for **long** configurations



**WA3018-G2**  
Battery door for **short** configurations

# Step 5:

## Choose a charging method



### Cradle options



#### Single Slot Cradle:

**WA4003-G2** Single slot USB cradle for short and long configurations.

**WA4003-AR** Single slot USB cradle for short and long configurations (Argentina).



The single slot cradle is compatible with the pistol grip, charges a spare battery and has USB master and slave connections.



The single slot cradle includes a power supply (PS1050-G1 or PS1050-AR for Argentina) with country adapters and a USB cable.



### Additional Adapters



**WA4015-G1**

USB to RS232 adapter



**WA4071**

USB to Ethernet adapter

# Step 5:

## Choose a charging method



### Cradle options



#### Four Slot Cradle:

**WA4204-G2** Four slot Ethernet cradle for all **long** configurations.

**WA4304-G2** Four slot Ethernet cradle for all **short** configurations.

The four slot cradle includes a power supply (PS1055-G1). Must purchase specific country AC Line Cord.



AC Line Cords:

- 9008693 for North America
- 9008892 for Europe
- 9008950 for UK

### Battery Charger



**WA3004-G1** Four slot battery charger to be used with high and ultra high capacity batteries. Includes power supply (PS1056-G1). Must order AC line cord separately.

# Step 5:

## Choose a charging method



### Cradle options

#### Vehicle cradle:

##### WA1210-G2

Vehicle cradle 12V, for use with **long** configurations

##### WA1310-G2

Vehicle cradle 12V, for use with **short** configurations

#### Vehicle charge cable:

##### RV3050


Vehicle charge cable, allows to charge directly any long or short configurations.



When using the vehicle cradle, the universal RAM mount is required (Order separately WA4006)



CA3002



CA1210

For powered connection, must order a power cable 9-20V input (CA1210) or the vehicle power outlet adapter cable (CA3002)



### Optional Accessories



##### WA4005-G1

Port replicator connects serial devices to the vehicle cradle.



##### PS1350

Pre-regulator module, required when connecting the vehicle cradle to power sources above 20V to a maximum of 72V.

# Step 6:

## Choose carrying accessories

### Carrying options

#### Holsters

**WA6083** Soft Holster and Belt for use with all short and long configurations when using the pistol grip. Includes belt, tether (pistol grip to holster) and leg strap.

**WA6084** Nylon Pouch for use with all short and long configurations when using the pistol grip. The nylon pouch is not approved in FCC countries.

#### Carry Cases

**WA6080** Standard carry case, for use with **long** configurations. Includes belt clip.

**WA6180** Standard Carry Case, for use with **short** configurations. Includes belt clip.

**WA6081** Carry case (open ended), for use with **long** configurations while using end cap scanners and most RFID options.

**WA6181** Carry case (open ended), for use with **short** configurations while using end cap scanners and most RFID options.

\* Note: Carry cases are not approved in FCC countries

#### Optional shoulder strap for carry cases

**CV6021**  
Shoulder strap for use  
with all carry cases.



# Step 6:

## Choose carrying accessories

### Carrying options

#### Rubber Boots

**WA6400** Rubber boot for use with **long LAN** configurations with/without using scanner pods/pistol grip

**WA6402** Rubber boot for use with **long extended range laser** configuration with/without using pistol grip

#### Optional shoulder strap for rubber boots

**CV6021** Shoulder strap for use with all rubber boots



WA6400  
Rubber Boot



WA6402  
Rubber Boot for Long  
Extended Range Laser



# Step 6:

## Choose carrying accessories

### Carrying options

#### Hand Straps

**WA6025** Hand strap with mobile stylus (double loop) for **long** configurations

**WA6125** Hand strap with stylus (double loop) for **short** configurations

Hand Straps include a tethered stylus



#### Miscellaneous

**WA6100-G1** Replacement end cap stylus (pack of 5)

**WA6310-G1** Mobile stylus with holder kit, includes stylus, tether and holder

**WA6113** Screen Protector (pack of 3)



**WA6025**  
Hand Strap with Mobile Stylus



**WA6310-G1**  
Mobile Stylus with Holder Kit

# Step 7:

## Choose optional tether adapters

### Cable options

#### Tether Open-Ended Cable



##### CA2950-G1

Open ended cable with strain relief (150mm/ 6ft)

#### Tether to Dsub9 Cable



##### WA4020-G2

Cable tether, provides RS232 connectivity (Dsub9 connector) to any short and long configurations through the tether port.

#### Tether to USB A Cable



##### WA1002

Cable tether, provides USB A connectivity to any short and long configurations through the tether port. Supports USB peripherals. Not used for active sync.